


BAYARD




MODLOFT



ASSEMBLY INSTRUCTION BAYARD MD103


PARTS



① x 1



② x 16




③ x 4



④ x 4



⑤ x 1



HARDWARE



M6x15mm

Ⓐ x 8



M5x60mm

Ⓑ x 8



M6x25mm

Ⓒ x 3



M5x40mm

Ⓓ x 16




φ13xφ6x1

Ⓔ x 11



φ11xφ5x1


Ⓕ x 48



M6x60mm

Ⓖ x 12

TOOL




Ⓗ x 1



ASSEMBLY INSTRUCTION


BAYARD MD103






ASSEMBLY INSTRUCTION

BAYARD MD103



BAYARD




MODLOFT




ASSEMBLY INSTRUCTION

BAYARD MD104

PARTS



① x 1



② x 6




③ x 6



④ x 1



⑤ x 1



HARDWARE



M6x15mm

Ⓐ x 17



M5x60mm

Ⓑ x 12



M5x40mm

Ⓓ x 6




φ13xφ6x1

Ⓔ x 17



φ11xφ5x1


Ⓕ x 36



M6x60mm

Ⓖ x 18

TOOL




Ⓗ x 1



ASSEMBLY INSTRUCTION

BAYARD MD104





ASSEMBLY INSTRUCTION

BAYARD MD104

